



EtherCAN

CAN-Ethernet Gateway



Hardware Manual

to Product C.2050.xx



NOTE

The information in this document has been carefully checked and is believed to be entirely reliable. **esd** makes no warranty of any kind with regard to the material in this document, and assumes no responsibility for any errors that may appear in this document. **esd** reserves the right to make changes without notice to this, or any of its products, to improve reliability, performance or design.

esd assumes no responsibility for the use of any circuitry other than circuitry which is part of a product of **esd gmbh**.

esd does not convey to the purchaser of the product described herein any license under the patent rights of **esd gmbh** nor the rights of others.

esd electronic system design gmbh

Vahrenwalder Str. 207
30165 Hannover
Germany

Phone: +49-511-372 98-0
Fax: +49-511-372 98-68
E-mail: info@esd-electronics.com
Internet: www.esd-electronics.com

USA / Canada:

esd electronics Inc.
525 Bernardston Road
Suite 1
Greenfield, MA 01301
USA

Phone: +1-800-732-8006
Fax: +1-800-732-8093
E-mail: us-sales@esd-electronics.com
Internet: www.esd-electronics.us

Document file:	I:\Texte\Doku\MANUALS\CAN\EtherCAN\Englisch\EtherCAN_13H.en9
Date of print:	2008-03-26

PCB version:	CANEGW Rev. 1.0
---------------------	-----------------

Changes in the chapters

The changes in the user's manual listed below affect changes in the **hardware**, as well as changes in the **description** of the facts only.

Chapter	Changes versus previous version
1.2.1	Current consumption documented.
6.	Graphics of connector pin assignment revised.
-	Declaration of CE conformity inserted.


Further technical changes are subject to change without notice.

This page is intentionally left blank.

Contents

1. Overview	7
1.1 Description of EtherCAN Module	7
1.2 Summary of Technical Data	8
1.2.1 General Technical Data	8
1.2.2 Microprocessor and Memory	8
1.2.3 CAN Interface	9
1.2.4 Ethernet Interface	9
1.2.5 Digital Inputs	10
1.2.6 Serial Interface (Service Interface)	10
1.2.7 Software Support	11
1.2.8 Order information	11
2. Front Panel View with LED Display	12
2.1 LEDs and Connectors in the Front Panel	12
2.2 Flashing Conditions	13
2.2.1 Flashing Conditions for Modules in AutoIP/DHCP Mode	13
2.2.2 Flashing Conditions for Modules in Firmware-Update Mode	13
2.2.3 Flashing Conditions for Modules with CAN Interface in Standard Operation	14
2.2.4 Flashing Conditions for Optional Modules with DeviceNet Interface	14
3. Service Interface	15
3.1 Default Setting	15
3.1.1 Configuration	15
3.1.2 Connecting the RS-232 Interface	15
4. Configuration	16
4.1 Configuration of the IP-Address	16
4.1.1 Configuration via AutoIP	17
4.1.2 Configuration via DHCP	18
4.2 Web based Configuration	19
4.2.1 TCP/IP-Default-Parameter	19
4.2.2 Overview	19
4.2.3 Configuration	20
4.2.3.1 Security	20
4.2.3.2 TCP/IP Network Configuration	21
4.2.3.3 Remote Logging Configuration	22
4.2.3.4 Firmware Update	23
4.2.4 Status	24
4.2.4.1 Status Ethernet	24
4.2.4.2 Status Events	25
5. Firmware Update	26
6. Connector Assignment	28
6.1 Connecting CAN and Ethernet	28
6.2 Connection for Power Supply and Digital Inputs (X300)	29
6.3 Ethernet Connection, RJ-45-Socket (X600)	30

6.4 CAN-Interface (X720)	31
6.4.1 Option: DeviceNet-Adapter boards	32
6.5 Serial Interface: Service Interface, RJ12-Socket (X200)	33
6.5.1 Serial Interface: DSUB Socket with Adapter Cable RJ12-DSUB9	34
7. Correctly Wiring Electrically Isolated CAN Networks	35
8. CAN-Bus Troubleshooting Guide	39
8.1 Termination	39
8.2 CAN_H/CAN_L Voltage	40
8.3 Ground	40
8.4 CAN Transceiver Resistance Test	41



1. Overview

1.1 Description of EtherCAN Module




Fig. 1.1: Block circuit diagram of EtherCAN module

The EtherCAN module is an Ethernet-CAN Gateway with a NET+50 ARM-Processor, which controls the data transfer between CAN and the Ethernet.

The Ethernet interface is suitable for 10 Mbit/s and 100 Mbit/s networks. It is connected via an RJ-45 socket in the front panel.

The CAN interface can be accessed via a 5-pole Combicon connector and is controlled by a SJA1000. The interface is in accordance with ISO11898, is electrically isolated and can be used for transmission rates of up to 1 Mbit/s. Optionally the module is available with DeviceNet interface.

The connectors for the Ethernet-, CAN- and serial interface and the status LEDs are located in the front panel of the top hat rail module and are easily accessible.

The 4-pole Combicon-connector for the power supply and both digital inputs is located in the case top side, also easily accessible.

The serial interface is used in the EtherCAN module only as service interface. It is realised as RS-232-interface and accessible via an RJ12 socket.



1.2 Summary of Technical Data

1.2.1 General Technical Data


Ambient temperature	0...50 °C
Humidity	max. 90 %, non condensing
Power supply	$U_{\text{NOM}} = 24 \text{ V}$
Current consumption	$I_{\text{TYP}} = 115 \text{ mA}$, $I_{\text{MAX}} = 130 \text{ mA}$
Connectors	X300 (4-pin Combicon MSTB connector, male) - power supply X600 (8-pin RJ-45-socket) - Ethernet X720 (5-pin Combicon MSTB-connector, male) - CAN interface for test and programming purposes only: X100 (8-pol. SMD-socket board) X200 (RJ12-socket) - serial interface RS-232-interface X210 (6-pol. SMD-socket board) - internal serial interface X700 (8-pol. SMD-socket board)
Dimensions	width: 23 mm, height: 100 mm, depth: 117 mm (including top hat rail mounting and projecting length of the connector)
Weight	130 g

Table 1.1: General technical data

1.2.2 Microprocessor and Memory

CPU	ARM-processor NET+50
Flash-EEPROM	up to 8 M x 8 bit (1, 2, 4, 8 MB)
Serial EEPROM	512 byte
SDRAM	from 2 M x 32 bit (8 MB) up to 4 M x 32 bit (16 MB)

Table 1.2: Microprocessor and Memory



1.2.3 CAN Interface

Number	1
CAN controller	SJA 1000
CAN protocol	according to ISO11898-1
Physical interface	Physical Layer according to ISO 11898-2, transmission rate programmable from 10 Kbit/s to 1 Mbit/s
Bus termination	has to be set externally
Electrical isolation	via optocoupler and DC/DC-converter
Connectors	X720, 5-pin Combicon connector
DeviceNet	optional DeviceNet interface instead of CAN interface, optocoupler and CAN driver according to DeviceNet specification 'DeviceNet Communication Model and Protocol, Rel. 2.0'

Table 1.3: CAN interface

1.2.4 Ethernet Interface

Number	1
Bit rate	10 Mbit/s, 100 Mbit/s
Transceiver	LXT971 ALC
Physical interface	Twisted-Pair (IEEE802.3) 10/100BaseT
Electrical isolation	via repeating coil
Connector	X600, 8-pin RJ-45-socket in the front panel

Table 1.4: Ethernet interface



1.2.5 Digital Inputs

The digital inputs are currently not supported by the software.


Number of digital inputs	2
Nominal voltage	24 V
Max. input voltage	24 V +10 %
Switching threshold	'0': $U_{IN} < 3 \text{ V}$ '1': $U_{IN} > 10 \text{ V}$
Input current at nominal voltage	max. 2.5 mA
Connector	X300, 4-pin Combicon connector (case top side)

Table 1.5: Digital inputs

1.2.6 Serial Interface (Service Interface)

Number	1
Controller	ARM-processor NET +50
Bit rate	Microcontroller: RS-232-transceiver: max. 115.200 bit/s
Physical interface	RS-232C
Connector	RJ12-socket in the front panel

Table 1.6: Serial interface



1.2.7 Software Support

The complete firmware is stored in the Flash-EEPROM and can be updated. The EtherCAN module can be configured by means of an arbitrary web-browser.

Additional driver software must be installed on the host-computer for operation as CAN-Gateway. The software is available for Windows NT/2000/XP and Linux and allows the use of the complete CAN-SDK incl. the monitor-program CANscope. The installation of the host-software is described in the manual 'CAN-API with Software Tools and Installation Notes'.


1.2.8 Order information

Type	Properties	Order No.
EtherCAN	CAN-Ethernet-Gateway	C.2050.02
EtherCAN-S7	CAN-Ethernet-Gateway incl. S7-example project with function modules to interface a S7-300/400 via Industrial Ethernet/UDP	C.2050.07
EtherCAN-ME	User manual in English ^{1*)} (this manual)	C.2050.20
CAN-API-ME	Software manual for the host software driver in English ^{1*)}	C.2001.21
EtherCAN-ENG	Engineering manual in English ^{2*)} Content: Circuit diagrams, PCB top overlay drawing, data sheets of significant components	C.2050.25

1 *)... If module and manual are ordered together, the manual is free of charge.

2 *)... This manual is liable for costs, please contact our support.

Table 1.7: Order information



LED-Display

2. Front Panel View with LED Display

The module is equipped with four LEDs in the front panel.

2.1 LEDs and Connectors in the Front Panel





Fig. 2.1: Front panel view

LED	Colour	Name	Display function (LED on)
LED600A	green	Activity	Receive status Ethernet (reception of Ethernet data)
LED600B	green	Link	Link Status Ethernet (link to server or hub)
LED600C	red	Error	The flashing conditions of these LEDs are described in the following tables for the different operation modes
LED600D	green	Run	

Table 2.1: Display function



2.2 Flashing Conditions

2.2.1 Flashing Conditions for Modules in AutoIP/DHCP Mode

For further information refer to the pages 17 and 18.

LED	Colour	Name	Flashing condition	Display
LED600C	red	Error	on	EtherCAN module in AutoIP/DHCP mode without configured IP-address
LED600D	green	Run	flashing	

Table 2.2.1: Display function of the LEDs in AutoIP/DHCP mode


2.2.2 Flashing Conditions for Modules in Firmware-Update Mode

For further information refer to the page ?.

The red Error LED (LED600C) and the green Run LED (LED600D) have the same flashing conditions.

LED	Flashing condition	Display
LED600C, LED600D	blinking (1 Hz)	Firmware-update mode active, no data transmission
	blinking (2 Hz)	Firmware-update mode active, data transmission active
	on	Firmware update completed

Table 2.2.2: Display function of the LEDs in firmware-update mode



LED-Display

2.2.3 Flashing Conditions for Modules with CAN Interface in Standard Operation


LED	Colour	Name	Flashing condition	Display
LED600C	rot	Error	off	no error
			blinking	warning level reached
			on	bus off
LED600D	green	Run	off	no host connection
			blinking	host activity (data exchange)
			on	host connection active

Table 2.2.3: Display functions of the LEDs for modules with CAN interface

2.2.4 Flashing Conditions for Optional Modules with DeviceNet Interface

LED	Status	To indicate:
red (Error): off green (Run): off	<i>Not Powered/Not On-line</i>	The module is not on-line. - The module has completed the Dup_MAC_ID test yet. - The module may not be powered.
red (Error): off green (Run): on	<i>Device Operational and On-line, Connected</i>	The module is operating in a normal condition and the device in on-line with connections in the <i>established</i> state.
red (Error): off green (Run): flashing	<i>Device Operational AND On-line , Not Connected or Device On-line AND Device needs commissioning</i>	The module works in normal condition and the module is on-line with <u>no</u> connections in the <i>established</i> state. - The module has passed the Dup_MAC_ID test, is on-line, but has no <i>established</i> connections to other nodes. - Configuration missing, incomplete or incorrect.
red (Error): flashing green (Run): off	Minor Fault and/or Connection Time-Out	Recoverable fault and/or one or more I/O Connections are in the <i>Timed-Out</i> state.
red (Error): on green (Run): off	Critical Fault or Critical Link Failure	The module has an unrecoverable fault; may need replacing. Failed communication device. The module has detected an error that has rendered it incapable of communicating on the network (Duplicate_MAC_ID or Bus-off).
red (Error): flashing green (Run): flashing	<i>Communication Faulted and Received an Identify Comm Fault Request-Long Protocol</i>	<i>A specific Communication Faulted device.</i> The module has detected a <i>Network Access</i> error and is in the <i>Communication Faulted</i> state. The device has subsequently received and accepted an <i>Identify Communication Faulted Request-Long Protocol Message</i> .

Table 2.2.4: Display function of the LEDs for modules with DeviceNet interface



3. Service Interface

Note: The serial interface is only for test- and programming purposes.

3.1 Default Setting

The default setting for both serial interfaces is as follows:

Bit rate: 9600 Baud
 Data bits: 8
 Parity: no
 Stop bits: 1
 Handshake: XON/XOFF

3.1.1 Configuration

The serial interface is controlled by NET+50 ARM processor. The bit rate of the interface can be configured. The serial controller NET+50 integrated and the RS-232 driver used for interface Serial 0 support bit rates up to 115.2 Kbit/s.

3.1.2 Connecting the RS-232 Interface

The figure below explains the short terms for the signals as used in the chapter (Connector Assignments). The signal terms are exemplary for the connection of the EtherCAN as a modem (DCE) via the adapter cable RJ12-DSUB9.





Fig. 3.1: Connection diagram for RS-232 operation



4. Configuration

The following chapter describes the configuration of the EtherCAN module, in two steps:

- ▶ Assignment of an IP-address
 - ▶ Configuration of the other parameters with a web-browser
- At the first putting into operation at least the subnet mask has to be set (see page 21).


The RJ-45-socket must be connected, as in normal operation, via a twisted pair wire with a switch or hub or via a cross twisted pair wire directly with the configuring host computer. The green (Link) LED flashing permanently indicates a correct connection.

4.1 Configuration of the IP-Address

First a valid IP-address must be assigned to the device. The IP-address is an unambiguous address for a device communicating in a TCP/IP-network. For configuration it is **important** to configure an IP-address which is **not** already assigned to another device in the network.

In delivery status after switching-on the device attempts to get assigned an IP-address by a DHCP-server. At the same time the device is in AutoIP-mode, which allows the simple assignment of an IP-address with an ARP-command.

If no IP-address has been assigned the red (Error) LED and the green (Link) LED are flashing permanently. The green (Run) LED blinks with 1 Hz and the green (Activity) LED is flickers depending on the network activity. After successful assignment of an IP-address the LEDs adopt the display functions described in chapter 2.



4.1.1 Configuration via AutoIP

The configuration via AutoIP is done by means of a manual entry in the ARP-table of a Windows- or UNIX-computer.

Note : The EtherCAN module and the computer must be in the **same subnet !**

The ARP-table serves the computer for conversion between IP-addresses and MAC-addresses. The additional entry is created in the command line of the Windows- or UNIX-computer by means of the ARP-command, whereby the user needs administrator rights.

The syntax for the command is:

```
arp -s <IP Address> <MAC Address>
```

<IP Address> is the unambiguous IP-address, that is assigned to the EtherCAN module. The 4 bytes of the IP-address are specified as decimal number separated by dots.

<MAC Address> is the MAC address of the device, which can be found on the label of the device. The 6 bytes of the MAC address are separated as hexadecimal number for Windows-computers by minus sign and for UNIX-computers by colons.

In a further step ICMP-packages have to be transmitted to the EtherCAN module by means of the *ping* command. If the module receives an ICMP-package addressed to it, it stores the configured IP-address in the EEPROM and reboots. The *ping* commando will return after this call with an error because the EtherCAN module answers only after the reboot with the IP-address specified.

The following text box shows an example.

The IP-address 10.0.16.121 is assigned to the EtherCAN module with the MAC-ID 00-02-27-80-00-05:

Windows:


```
arp -s 10.0.16.121 00-02-27-80-00-05  
ping -t 10.0.16.121
```

Unix:

```
arp -s 10.0.16.121 00:02:27:80:00:05  
ping 10.0.16.121
```

The further configuration of the network parameter after the reboot can be done by means of any web-browser as described in the following chapter (see page 21).

The host of the web-browser must be in the same subnet, under the URL **http://<IP Address>**.



Configuration


4.1.2 Configuration via DHCP

For a configuration via DHCP a DHCP-server has to be in the **same subnet** as the EtherCAN module. If necessary a specific DHCP-server must be configured. Please, contact your system administrator.

The server assigns to the module a valid IP-address, a network mask, a gateway address and the IP-address of a name server. After successful assignment the module works with these data without rebooting.

The IP-address **<IP Address>** assigned to the device has to be determined by means of the logging-mechanisms of the DHCP-server. The further configuration of the network parameter can be done by any web-browser, which is in the same subnet, under the URL **http://<IP Address>**, as described in the following chapter.

Note: Without further configuration a DHCP-server might possibly assign a different IP-address to a device at every reboot and this only for a specific period. It is important for the driver software on the host-computer that the IP-address is always the same and not changed during the entire operation period. If the IP-address shall be assigned via DHCP to the EtherCAN module at every reboot, the system administrator has to ensure that.



4.2 Web based Configuration

4.2.1 TCP/IP-Default-Parameter

The EtherCAN offers an integrated HTTP-server, which allows the further configuration with a web-browser. The default-TCP/IP-network parameters at the first putting into operation are the following:

IP-Address:	as described above
Subnet Mask:	0.0.0.0
Default Gateway:	0.0.0.0
Name Server:	0.0.0.0
Time Server:	0.0.0.0

4.2.2 Overview

In the menu item *Overview* the module specific parameters are shown. The specifications under *Gateway status* refer to the CAN interface of the EtherCAN.

CAN-Ethernet Gateway esd gmbh, Hannover

Overview

Overview

Configuration

- Security
- TCP/IP settings
- Remote logging
- Firmware update

Status

- Ethernet
- Events

Information

- Contact

Gateway details


Order number	Serial number	Firmware revision	Hardware revision
C.2050.02	AB00000005	4.0.08	1.1

Gateway status

Bus Status	Error status	Baudrate	Client connections
BUS-ON	OK	Unconfigured	0

esd
electronic system
design gmbh

Fig. 4.2.1: Overview



Configuration

4.2.3 Configuration

All settings specified in the column *Configuration* are protected by a combination of user name and password. The default settings at delivery are:

User Name: Administrator
Password:

In the default setting **no** character has to be entered for *Password*.

4.2.3.1 Security


On this page user name and password can be changed. User name and password are required for the firmware update, described in a special chapter.

User name and password can be adapted arbitrarily. Please pay attention to case sensitivity.

Clicking the *submit* button saves the changed data in a non-volatile memory of the EtherCAN module. After reboot the new data is active.

The screenshot shows the 'Security Setup' page of the 'CAN-Ethernet Gateway' web interface. The page title is 'CAN-Ethernet Gateway' and the company name 'esd gmbh, Hannover' is in the top right. A left sidebar contains navigation links: Overview, Configuration (selected), Security, TCP/IP settings, Remote logging, Firmware update, Status, Ethernet, Events, Information, and Contact. The main content area is titled 'Security Setup' and contains the following text: 'This page is intended to configure a user name and a password to restrict the access to gateway configuration parameter and the possibility to update the gateway firmware.' Below this text are two input fields: 'User Name: [input] (Max. 15 characters)' and 'Password: [input] (Max. 15 characters)'. At the bottom of the form are 'Reset' and 'Submit' buttons. The footer of the page features the 'esd' logo and the text 'electronic system design gmbh'.

Fig. 4.2.2: Setting user name and password



4.2.3.2 TCP/IP Network Configuration

On this page the basic TCP/IP-parameters can be configured. The active settings are displayed in brackets. If the IP-address is configured via DHCP, these are the assigned values.

If the IP-address is set to the value 0.0.0.0 , the module falls back into the boot mode described in the chapter above.

At the first putting into operation at least the subnet mask has to be adapted to the conditions of the net.


If the EtherCAN module shall be accessed via a Gateway, its IP-address has to be entered, otherwise the parameter should be set to 0.0.0.0.

Optionally the addresses of a name server and a time server can be configured. They will be evaluated in the *Remote Logging* as described in the following chapter.

If the check box *Use DHCP* is activated the IP-address is configured via DHCP. This might cause the problems described in chapter ‘Configuration via DHCP’ on page 18.

Clicking the *submit* button saves the changed data in the non-volatile memory of the EtherCAN module. After reboot the new data is active.

Fig. 4.2.3: TCP/IP-Configuration



Configuration

4.2.3.3 Remote Logging Configuration

On this page *Remote Logging* support of the EtherCAN module can be activated and configured. The module offers the option not only to provide occurred alarms and events at the local HTTP-server, but also to transmit them as email to a SMTP-server.

With the checkbox *Email* the *Remote Logging* support can be activated or deactivated.

With the check boxes *Errors*, *Warnings* and *Infos* it can be configured which events trigger the transmission of the eventlogs as email.


In the field *SMTP Server* the IP-address or the computer name of the SMTP server can be entered. The use of the computer name is only possible if a name server has been configured (see page 21).

In the field *From* and *To* the addresses of the email can be entered.

Clicking the *submit* button saves the changed data in the non-volatile memory of the EtherCAN module. After reboot the new data is active.

The screenshot shows a web interface for 'CAN-Ethernet Gateway' by 'esd gmbh, Hannover'. The main heading is 'Remote Logging Configuration'. A sidebar on the left contains navigation links: Overview, Configuration (selected), Security, TCP/IP settings, Remote logging, Firmware update, Status, Ethernet, Events, Information, and Contact. The main content area includes a descriptive paragraph: 'This page is intended to configure remote logging of alarms and events. If you don't enter the address of the mail server in dotted decimal form you have to configure the name server in "TCP/IP Settings". After pressing the "Submit" button on this page a testmail is send to the configured server.' Below this is a form with the following fields: 'Logging by:' with a checkbox for 'Email'; 'Send Email on:' with checkboxes for 'Errors', 'Warnings', and 'Infos'; 'SMTP Server:' with a text input field and '(IP Address or hostname)' label; 'From:' with a text input field and '(Max. 31 characters)' label; and 'To:' with a text input field and '(Max. 31 characters)' label. At the bottom of the form are 'Reset' and 'Submit' buttons. The footer of the interface shows the 'esd' logo and 'electronic system design gmbh'.

Fig. 4.2.4: Configuration of the Remote Logging



4.2.3.4 Firmware Update

With this page the EtherCAN module can be switch to the firmware update mode to update the local firmware after next reboot. The exact details of the firmware update are described in the chapter on page 26.





Fig. 4.2.5: Firmware update



Configuration

4.2.4 Status

4.2.4.1 Status Ethernet

This page shows a series of static parameters of the Ethernet link, the actual connection speed (10/100 Mbit/s) and category (half/full duplex) and the MAC-ID of the EtherCAN module.

CAN-Ethernet Gateway esd gmbh, Hannover

Overview **Ethernet parameter**

Overview

Configuration

Security

TCP/IP settings

Remote logging

Firmware update


Status

Ethernet

Events

Information

Contact



 esd
 electronic system
 design gmbh

MAC Address		Speed		Communication	
00-02-27-80-00-05		100 MBit/s		Full Duplex	

Ethernet statistics

Receive Statistics		Transmit Statistics		Misc Errors	
Bytes	0	Bytes	0	Net Restarts	0
Packets	5353	Packets	504	Memory Errors	0
Multicast Packets	0	Multicast Packets	0		
CRC Errors	0	Late Collisions	0		
Framing Errors	0	Excessive Deferrals	0		
Overrun Errors	1536	Excessive Collisions	0		
Buffer Overflow	0	Buffer Underrun	0		
Discarded	1536				


Fig. 4.2.6: Ethernet status



4.2.4.2 Status Events

On this page alarms and events from the start of the EtherCAN module are shown. The events are classified depending on the severity into the category *Error*, *Warning* or *Info*. The list will be deleted at a reboot of the module. During runtime of the module the list can be transmitted per email to another computer (see page 22).

For correct date and time a time server has to be configured (see page 21). Else the calculation of times starts after the reboot of the EtherCAN modules always at 01.01.1970 at 0.00 a.m..



The screenshot shows the 'CAN-Ethernet Gateway' web interface for 'esd gmbh, Hannover'. The left sidebar contains navigation options: Overview, Configuration (selected), Security, TCP/IP settings, Remote logging, Firmware update, Status, Ethernet, Events (highlighted), Information, and Contact. The main content area is titled 'Alarms and Events' and displays a table with the following data:

Date	Time	Event
22.09.03	08:29:13	CAN-Ethernet Gateway booted (Firmware: 4.0.08)

Below the table is a legend for event severity levels:

Legend: ■ Error ■ Warning ■ Info

The footer of the interface displays the 'esd' logo and the text 'electronic system design gmbh'.

Fig. 4.2.7: Event list



5. Firmware Update

The firmware of the EtherCAN modules can be updated by means of a standard FTP-client. The firmware update mode is activated by means of a web-browser (see page 23). After the reboot of the device the red (Error) LED and the green (Run) LED flash permanently once per second. The other functions of the EtherCAN module are not available in this mode.

The connection to the EtherCAN FTP server, which is active only in this mode, can be done by means of a FTP-client. The settings used for the authentication at the configuration via the web-browser (see page 20) are used as user name and password.


During data transmission to the FTP-server on the EtherCAN module the red Error LED and the green Run LED are blinking synchronous twice per second. After finishing data transmission both LEDs are permanently active and the module reboots with the new firmware.

Note: During firmware update neither the current supply of the EtherCAN module nor the network link between FTP server and client may be disconnected, because otherwise the module might get into a state where it is no longer operative!

The following example shows the run of the update with the FTP command of Windows 2000. The entries of the user are bold.

It is very important to switch the transmission mode of the FTP server to binary data transmission (FTP command **binary**) before the firmware update and to quit the FTP-client correctly (FTP command **quit**), because the last part of the data will be processed on the EtherCAN module only at that moment.

```
ftp 10.0.16.121
Connected to 10.0.16.121.
220 NET+ARM FTP Server 1.0 ready.
User (10.0.16.121:(none)): Administrator
331 User OK, send password.
Password:
230 Password OK.
ftp> binary
200 Type set to I.
ftp> hash
Hash mark printing On ftp: (2048 bytes/hash mark) .
ftp> put cegw4008.bin
200 PORT command Ok.
150 About to open data connection.
#####
226 Transfer complete
ftp: 982556 bytes sent in 14,05Seconds 69,93Kbytes/sec.
ftp> quit
221 Goodbye.
```



6. Connector Assignment

6.1 Connecting CAN and Ethernet





Fig. 6.1.1: Connection of CAN and Ethernet



Connector Assignment


6.2 Connection for Power Supply and Digital Inputs (X300)

The Connector X300 is of 4-pin Phoenix Combicon type located at the top side of the case.

Device Connector: COMBICON MSTBO 2,5/4-G1R-KMGY

Line Connector: COMBICON FKCT 2,5/4-ST, 5.0 mm pitch, spring-cage connection, PHOENIX-CONTACT order no.: 19 21 90 0 (included in the scope of delivery)

Pin Position:



Pin Assignment:


Pin	4	3	2	1
Signal	+24 V	GND	XDIN1	XDIN0

Signal Description:

+24 V... power supply


GND... reference potential

XDIN1, XDIN0... digital inputs



6.3 Ethernet Connection, RJ-45-Socket (X600)

Pin Position:




Cut-out for
fixing

Pin Assignment:

Pin	Signal
1	TP01 (TxD+)
2	TP02 (TxD-)
3	TP03 (RxD+)
4	TP04
5	TP05
6	TP06 (RxD-)
7	TP07
8	TP08

8-pin RJ-45-socket




Connector Assignment

6.4 CAN-Interface (X720)

Device Connector: COMBICON MSTB 2,5/5 G-5,08-RN-AU
Line Connector: COMBICON FKC2,5/5-ST-5,08-RF-AU, spring-cage connection,
(included in the scope of delivery)

Pin Position:




Pin Assignment:

Pin	Signal
1	CAN_GND
2	CAN_L
3	Shield
4	CAN_H
5	reserved

Signal description:

CAN_GND... reference potential to CAN+/CAN-
CAN_H, CAN_L... CAN signal lines
Shield... shielding
(connected to top hat rail (ground) via high-impedance RC-member)



6.4.1 Option: DeviceNet-Adapter boards

The DeviceNet interface has been constructed in accordance with the specification 'DeviceNet Communication Model and Protocol, Rel. 2.0'. The power supply for the CAN bus driver is supplied externally.

Device Connector: COMBICON MSTB 2,5/5 G-5,08-RN-AU

Line Connector: COMBICON FKC2,5/5-ST-5,08-RF-AU, spring-cage connection, (included in the scope of delivery)

Pin Position:




Pin Assignment:

Pin	Signal
1	V-
2	CAN-
3	Shield
4	CAN+
5	V+

Signal Description:

V+...	power supply ($U_{VCC} = 24\text{ V} \pm 4\%$)
V-...	reference potential to V+ and to CAN+/CAN-
CAN+, CAN-...	CAN signal lines
Shield...	shield (connected to top hat rail (ground) via high-impedance RC-member)




Connector Assignment

6.5 Serial Interface: Service Interface, RJ12-Socket (X200)

For notes to the connection of serial interfaces please refer also to chapter ‘Serial Interfaces’ on page 15. From the principle circuit diagrams represented in that chapter, you will be able to clearly determine the direction (Rx \leftrightarrow Tx).

Pin Position:




Cut-out for
fixing

Pin Assignment:


Pin	Signal
1	+5 V
2	TxD Data Output
3	RxD Data Input
4	RTS Handshake Output
5	CTS Handshake Input
6	GND

The data direction of the signals is given as viewed from the EtherCAN module.



6.5.1 Serial Interface: DSUB Socket with Adapter Cable RJ12-DSUB9

Pin Position:




Pin Assignment:

Signal	Pin		Signal	
n.c.	1	6	n.c.	
RxD (Output)	2		7	RTS (Input)
TxD (Input)	3		8	CTS (Output)
n.c.	4		9	n.c.
GND	5			

9-pin DSUB-Socket

n.c. ... not connected

The signal names are specified as viewed from the terminal (PC). The signal direction specified in brackets is shown as viewed from the EtherCAN module.



Wiring

7. Correctly Wiring Electrically Isolated CAN Networks

Generally all instructions applying for wiring regarding an electromagnetic compatible installation, wiring, cross sections of wires, material to be used, minimum distances, lightning protection, etc. have to be followed.

The following **general rules** for the CAN wiring must be followed:

1.	A CAN net must not branch (exception: short dead-end feeders) and has to be terminated by the wave impedance of the wire (generally $120 \Omega \pm 10\%$) at both ends (between the signals CAN_L and CAN_H and not at GND)!
2.	A CAN data wire requires two twisted wires and a wire to conduct the reference potential (CAN_GND)! For this the shield of the wire should be used!
3.	The reference potential CAN_GND has to be connected to the earth potential (PE) at one point. Exactly one connection to earth has to be established!
4.	The bit rate has to be adapted to the wire length.
5.	Dead-end feeders have to kept as short as possible ($l < 0.3 \text{ m}$)!
6.	When using double shielded wires the external shield has to be connected to the earth potential (PE) at one point. There must be not more than one connection to earth.
7.	A suitable type of wire (wave impedance ca. $120 \Omega \pm 10\%$) has to be used and the voltage loss in the wire has to be considered!
8.	CAN wires should not be laid directly next to disturbing sources. If this cannot be avoided, double shielded wires are preferable.





Figure: Structure and connection of wire



Cabling

- for devices which have only one CAN connector per net use T-connector and dead-end feeder (shorter than 0.3 m) (available as accessory)





Figure: Example for correct wiring (when using single shielded wires)

Terminal Resistance

- use **external** terminator, because this can later be found again more easily!
- 9-pin DSUB-terminator with male and female contacts and earth terminal are available as accessories

Earthing

- CAN_GND has to be conducted in the CAN wire, because the individual esd modules are electrically isolated from each other!
- CAN_GND has to be connected to the earth potential (PE) at **exactly one** point in the net!
- each CAN user without electrically isolated interface works as an earthing, therefore: do not connect more than one user without potential separation!
- Earthing CAN e.g. be made at a connector




Wiring

Wire Length

- Optical couplers are delaying the CAN signals. By using fast optical couplers and testing each board at 1 Mbit/s, esd modules typically reach a wire length of 37 m at 1 Mbit/s within a closed net without impedance disturbances like e.g. longer dead-end feeders.

Bit rate [Kbit/s]	Typical values of reachable wire length with esd interface l_{\max} [m]	CiA recommendations (07/95) for reachable wire lengths l_{\min} [m]
1000	37	25
800	59	50
666.6	80	-
500	130	100
333.3	180	-
250	270	250
166	420	-
125	570	500
100	710	650
66.6	1000	-
50	1400	1000
33.3	2000	-
20	3600	2500
12.5	5400	-
10	7300	5000


Table: Reachable wire lengths depending on the bit rate when using esd-CAN interfaces



Examples for CAN Wires

Manufacturer	Type of wire
U.I. LAPP GmbH Schulze-Delitzsch-Straße 25 70565 Stuttgart Germany www.lappkabel.de	e.g. UNITRONIC ®-BUS CAN UL/CSA (UL/CSA approved) UNITRONIC ®-BUS-FD P CAN UL/CSA (UL/CSA approved)
ConCab GmbH Äußerer Eichwald 74535 Mainhardt Germany www.concab.de	e.g. BUS-PVC-C (1 x 2 x 0.22 mm ²) Order No.: 93 022 016 (UL appr.) BUS-Schleppflex-PUR-C (1 x 2 x 0.25 mm ²) Order No.: 94 025 016 (UL appr.)
SAB Bröckskes GmbH&Co. KG Grefrather Straße 204-212b 41749 Viersen Germany www.sab-brockskes.de	e.g. SABIX® CB 620 (1 x 2 x 0.25 mm ²) Order No.: 56202251 CB 627 (1 x 2 x 0.25 mm ²) Order No.: 06272251 (UL appr.)

Note: Completely configured CAN wires can be ordered from **esd**.



8. CAN-Bus Troubleshooting Guide

The CAN-Bus Troubleshooting Guide is a guide to find and eliminate the most frequent hardware-error causes in the wiring of CAN-networks.




Figure: Simplified diagram of a CAN network

8.1 Termination

The termination is used to match impedance of a node to the impedance of the transmission line being used. When impedance is mismatched, the transmitted signal is not completely absorbed by the load and a portion is reflected back into the transmission line. If the source, transmission line and load impedance are equal these reflections are eliminated. This test measures the series resistance of the CAN data pair conductors and the attached terminating resistors.

To test it, please

1. Turn off all power supplies of the attached CAN nodes.
2. Measure the DC resistance between CAN_H and CAN_L at the middle and ends of the network (1) (see figure above).


The measured value should be between 50 Ω and 70 Ω. The measured value should be nearly the same at each point of the network.

If the value is below 50 Ω, please make sure that:

- there is no short circuit between CAN_H and CAN_L wiring
- there are not more than two terminating resistors
- the nodes do not have faulty transceivers.

If the value is higher than 70 Ω, please make sure that:

- there are no open circuits in CAN_H or CAN_L wiring
- your bus system has two terminating resistors (one at each end) and that they are 120 Ω each.



8.2 CAN_H/CAN_L Voltage

Each node contains a CAN transceiver that outputs differential signals. When the network communication is idle the CAN_H and CAN_L voltages are approximately 2.5 volts. Faulty transceivers can cause the idle voltages to vary and disrupt network communication.

To test for faulty transceivers, please

1. Turn on all supplies.
2. Stop all network communication.
3. Measure the DC voltage between CAN_H and GND **2** (see figure above).
4. Measure the DC voltage between CAN_L and GND **3** (see figure above).

Normally the voltage should be between 2.0 V and 4.0 V.

If it is lower than 2.0 V or higher than 4.0 V, it is possible that one or more nodes have faulty transceivers. For a voltage lower than 2.0 V please check CAN_H and CAN_L conductors for continuity. For a voltage higher than 4.0 V, please check for excessive voltage.

To find the node with a faulty transceiver please test the CAN transceiver resistance (see next page).

8.3 Ground

The shield of the CAN network has to be grounded at only one location. This test will indicate if the shielding is grounded in several places. To test it, please

1. Disconnect the shield wire (Shield) from the ground.
2. Measure the DC resistance between Shield and ground (see picture on the right hand).
3. Connect Shield wire to ground.





Fig.: Simplified schematic diagram of ground test measurement

The resistance should be higher than 1 MΩ. If it is lower, please search for additional grounding of the shield wires.



8.4 CAN Transceiver Resistance Test

CAN transceivers have one circuit that controls CAN_H and another circuit that controls CAN_L. Experience has shown that electrical damage to one or both of the circuits may increase the leakage current in these circuits.

To measure the current leakage through the CAN circuits, please use an resistance measuring device and:

1. Disconnect the node from the network. Leave the node unpowered (4) (see figure below).
2. Measure the DC resistance between CAN_H and CAN_GND (5) (see figure below).
3. Measure the DC resistance between CAN_L and CAN_GND (6) (see figure below).

Normally the resistance should be between 1 M Ω and 4 M Ω or higher. If it is lower than this range, the CAN transceiver is probably faulty.




Figure: Simplified diagram of a CAN node

EG-KONFORMITÄTSERKLÄRUNG DECLARATION OF CONFORMITY



Adresse
Address

esd electronic system design gmbh
Vahrenwalder Str. 207
30165 Hannover
Germany

esd erklärt, daß das Produkt
esd declares, that the product

EtherCAN

Typ, Modell, Artikel-Nr.
Type, Model, Article No.

C.2050.02

die Anforderungen der Normen
fullfills the requirements of the standards

**EN 61000-6-4 (08/2002)
EN 61000-6-2 (08/2002)**

gemäß folgendem Prüfbericht erfüllt.
according to test certificate.

H-K00-0271-06

Das Produkt entspricht damit den EG-Richtlinien
Therefore the product corresponds to the EU-Directives

**89/336/EWG geändert durch
(changed by) 91/263/EWG,
92/31/EWG and 93/68/EWG**

Diese Erklärung gilt für alle Exemplare, die das CE-Zeichen tragen und verliert ihre Gültigkeit,
wenn Veränderungen am Produkt vorgenommen werden.
*This declaration is valid for all units with the CE label on it and it lose its validity if a modification
is done on the product.*

Name / Name
Funktion / Title
Datum / Date

Dr. Ing. Werner Schulze
Geschäftsführer / Managing Director
Hannover, den 29.02.2008

Rechtsgültige Unterschrift / *authorized Signature*